

Wiring Diagram for Freightliner PN: SI 440 U

Contact Information: Jim Hoffman, Engineer, at 260.517.9580

NAVISTAR/FREIGHTLINER

With MD or EVS Allison Transmission

Vehicles with a programmable Automatic Transmission, the Transmission must be programmed with a Negative Ground Signal for the PARK/NEUTRAL Circuit.
This programming needs to be done by a qualified Allison, Navistar or Freightliner Technician.

